Index

• A •

accessing
  Automatic White Balance (AWB) setting, 266
  Drive modes, 45
  images, 307–312
  White Balance Correction, 271–273
action photography
  about, 293
  autofocus combinations for, 257
  techniques for, 294–297
adding
  cleaning instructions to images, 342–345
  text, 332–333
A-DEP (auto depth of field)
  about, 197
  flash in, 240
  Picture Styles in, 281
  relationship with depth of field, 262
  settings, 208
  using, 263–264
adjusting
  AF (autofocus) mode, 255–257
  aperture, 214–216
  autofocus performance, 252–257
  automatic rotation, 138
  camera settings, 25–34
  color balance, 320–321
  color saturation, 317–319
  depth of field, 258–261
  Drive mode, 43–47
  exposure, 322–328
  flash power with Flash Exposure Compensation, 242–244
  functions of Set button, 335–337
  Image Review, 131–132
  picture settings, 109–114
  Picture Styles, 282
  Scene mode results, 78–87
  settings with Quick Control button, 112
  "Shoot by" settings, 84–87
  Shooting Settings display settings, 29
  shutter speed, 214–216
  White Balance setting, 267–268
Adobe Photoshop, 167
Adobe Photoshop Elements, 166
Adobe Photoshop Lightroom, 166
Adobe RGB, compared with sRGB, 277–279
advanced exposure modes. *See also* Creative Zone category; *specific exposure modes*
  about, 196–197
  enabling flash in, 50
  using flash in, 235–247
AE Lock, canceling, 120
AE Lock/AF, 338
AE Lock/FE Lock/Index/Reduce button, 21
AE/AF, no AE Lock, 339
AEB (automatic exposure bracketing)
  about, 230
  in Continuous mode, 235
  disabling, 234
  in Single mode, 235
  symbol, 113
AF (autofocus) mode
  about, 102–109, 252
  adjusting performance, 252–257
  changing, 255–257
  choosing combinations, 257
  setting, 256–257
  setting AF mode with button, 256
  shifting to manual focus from, 11–13
AF Mode (Movie Menu 1), 121
AF Point Selection, 252
AF Point Selection button, 113
AF Point Selection/Magnify button, 21
AF Selection Point, 253–255
AF w/Shutter Button During Movie (Movie Menu 1), 121
AF/AE Lock, 338
AF/AF Lock, no AE Lock, 338–339

COPYRIGHTED MATERIAL

AF-assist beam
  about, 67
  disabling, 340–341
AI Focus mode, 255–256
AI Servo mode, 255
anti-shake, 10–11
aperture
  about, 197–198, 201
  adjusting, 214–216
  adjusting depth of field with, 258, 260
  effect on depth of field, 201
  in Portrait mode, 73
  setting, 73, 214–216
  setting in Portrait mode, 73
Aperture (Apple), 166
Aperture/Exposure Compensation/Erase button, 21
aperture-priority autoexposure (Av)
  about, 196
  changing exposure settings in, 214
  for dynamic close-up photography, 300
  exposure compensation in, 220
  flash in, 239
  Picture Styles in, 281
  relationship with depth of field, 261
  for scenic photography, 297
  settings, 207
  for still portraits, 288
Apple
  Aperture, 166
  iPhoto, 165
  website, 165
attaching lenses, 8–10
Auto Adjustment option, 331–332
auto depth of field (A-DEP)
  about, 197
  flash in, 240
  Picture Styles in, 281
  relationship with depth of field, 262
  settings, 208
  using, 263–264
Auto Lighting Optimizer
  about, 223–226
  automatic exposure bracketing (AEB) in, 231
  in Highlight Tone Priority, 221
  Movie Menu 3, 124
Auto mode, 48
Auto Power Off, 34–35
Auto Reset file numbering, 35–36
Auto Rotate, 34, 35
autoexposure
  locking settings, 228–230
  overriding with Exposure Compensation, 216–220
autofocus (AF) mode
  about, 102–109, 252
  adjusting performance, 252–257
  changing, 255–257
  choosing combinations, 257
  setting, 256–257
  setting AF mode with button, 256
  shifting to manual focus from, 11–13
autofocusing
  in Close-up mode, 76
  in Flash Off mode, 70
  in Full Auto mode, 70
  in Landscape mode, 75
  Live mode, 107–108
  in Night Portrait mode, 78
  in Portrait mode, 74
  Quick mode, 104–107
  in Sports mode, 77
auto-launching Canon programs, 173–174
automatic exposure bracketing (AEB), 113, 230
  in Continuous mode, 235
  disabling, 234
  in Single mode, 235
  symbol, 113
automatic rotation, 138
Automatic White Balance (AWB) setting, 266
Av (aperture-priority autoexposure)
  about, 196
  changing exposure settings in, 214
  for dynamic close-up photography, 300
  exposure compensation in, 220
  flash in, 239
  Picture Styles in, 281
  relationship with depth of field, 261
  for scenic photography, 297
  settings, 207
  for still portraits, 288
AWB (Automatic White Balance) setting, 266

• B •

Background Blur feature, in Creative Auto mode, 89–91
backgrounds
  checking, 290
  softening, 288
backlighting, shooting in, 303–304
balancing exposure, 204–205
Basic Information mode, 142–143
Basic Information plus display, 143
Basic Zone category, 42–43
battery
  in Live View, 97
  preserving, 29
Beep, 34, 40
bit depth, 63, 179
blinking spots, 146
blown highlights, 147
book
  icons, 3
  software, 4
bracketed series, shooting, 235
bracketing
  automatic exposure bracketing (AEB) in, 231
  exposures, 230–235
  as lighting tip, 300
  with white balance, 274–277
Brighter setting, 80
brightness histogram, 99, 144, 147–148
buffer, 118
built-in flash, 47, 236. *See also* flash
Built-in Flash Function Setting options, 246–247
burst mode, 44
buttons
  AE Lock/FE Lock/Index/Reduce, 21
  AF Point Selection/Magnify, 21, 113
  Aperture/Exposure Compensation/Erase, 21
  Depth-of-Field Preview, 264
  Disp, 22
  Exposure Compensation, 218
  Flash, 19, 341–342
  LCD Off/On, 37
  lens release, 24
  Live View/Movie, 21
  Menu, 23
  Playback, 23
  Quick Control/Direct Print, 22
  Set, 22, 335–337
  Shutter, 19, 37, 290
  WB, 267–268

• C •

calibrating monitors, 183–184
camera controls (external)
  back-of-the-body, 19–23
  connection ports, 24–25
  front, 23–24
  topside, 17–19
Camera Raw (CR2) files, 62–64, 176–180
camera settings
  about, 25
  adjusting, 25–34
  Camera Settings display, 33–34
  menus, 26–28
  Quick Control screen, 30–31
  Shooting Settings display, 28–30
  viewfinder data, 31–33
  viewing, 25–34
Camera Settings display, 33–34
camera shake, 97
cameras, connecting to computers, 168–169
camera-to-subject distance, 259
canceling AE Lock, 120
Canon. *See also specific topics*
  tools, 170–176
  website, 3, 39, 168, 237
Canon Digital Photo Professional, 165–166, 283
Canon EX-series Speedlites, 247
Canon ZoomBrowser EX (Windows), 164–165
car windows, shooting through, 303
Carr, Pete (author)
  HDR Photography Photo Workshop, 232, 299
Center-Weighted Average metering, 208

changing
AF (autofocus) mode, 255–257
aperture, 214–216
autofocus performance, 252–257
automatic rotation, 138
camera settings, 25–34
color balance, 320–321
color saturation, 317–319
depth of field, 258–261
Drive mode, 43–47
exposure, 322–328
flash power with Flash Exposure Compensation, 242–244
functions of Set button, 335–337
Image Review, 131–132
picture settings, 109–114
Picture Styles, 282
Scene mode results, 78–87
settings with Quick Control button, 112
"Shoot by" settings, 84–87
Shooting Settings display settings, 29
shutter speed, 214–216
White Balance setting, 267–268
channels, 63
Cheat Sheet, 4
checking
background, 290
Camera Settings display, 33–34
depth of field, 264–265
choosing
autofocus combinations, 257
color space, 277–279
exposure metering mode, 208–210
exposure modes, 42–43
functions on menus, 28
menus, 28
photo software, 163–167
resolution, 181
Clean Manually option (Setup Menu 2), 38
cleaning
adding instructions to images, 342–345
LCD monitor, 15
Clear Settings option (Setup Menu 3), 39
clipped highlights, 147
Close-up mode, 42, 48, 75–76
close-up photography, dynamic, 300–302
closing EOS Utility, 174
Cloudy setting, 83
color
about, 265
changing White Balance setting, 267–269
controlling, 265–277
correcting with white balance, 265–267
creating custom White Balance settings, 269–271
fine-tuning White Balance settings, 271–273
in Flash Off mode, 70
in Full Auto mode, 70
syncing print and monitor, 183–186
White Balance Bracketing, 273–277
color balance, 320–321
color casts
about, 53
eliminating with Shoot by Lighting or Scene Type option, 82–84
color management tools, 185, 277
color saturation, 317–319
color space
about, 33
choosing, 277–279
defined, 249
color temperature, 265
colorimeter, 184
components
external camera controls, 17–25
LCD monitor, 14–16
lenses, 8–13
memory cards, 16–17
viewfinder, 13–14
compression
JPEG, 56
lossy, 61
computerless printing, 186
computers
connecting cameras to, 168–169
sending pictures to, 167–176
connecting camera to computers, 168–169
connection ports, 24–25
Continuous drive mode, 44
Continuous file numbering, 35
Continuous mode, 235
controlling
color, 265–277
ISO, 211–212
picture quality, 52–56

controls, external camera
  back-of-the-body, 19–23
  connection ports, 24–25
  front, 23–24
  topside, 17–19
Cool setting, 80
copyright data, tagging files with, 349–351
Copyright Information option (Setup Menu 3), 39
correcting
  color with white balance, 265–267
  lens vignetting, 226–228
correction tools (exposure)
  Exposure Compensation, 216–220
  Highlight Tone Priority, 220–226
  Peripheral Illumination Correction, 226–228
Correll, Robert (author)
  HDR Photography Photo Workshop, 232, 299
  High Dynamic Range Digital Photography For Dummies, 232, 299
CR2 (Raw) files, 62–64, 176–180
creating
  camera menus, 346–348
  custom folders, 348–349
  custom white balance settings, 269–271
  Picture Styles, 283
  slide shows, 156–160
Creative Auto mode
  about, 42, 87–92
  flash in, 235
  Picture Styles in, 280
  relationship with depth of field, 261
  using flash in, 48–49
Creative Zone category, 43
crop factor, 262
cropping images, 314—317
cross keys, 22, 113, 212
Custom Functions option (Setup Menu 3), 39
Custom White Balance (Movie Menu 3), 124
customizing
  exposure lock options, 338–339
  focus lock options, 338–339
  Live View display, 98–100
  menus, 348
  movie recording settings, 119–124
  options, 39–40

• D •

dampening noise, 213
Darker setting, 80
data, 31–33
Datacolor Spyder3Express, 184
Date, 34
Date/Time option (Setup Menu 2), 37–38
Daylight setting, 83
decoding viewfinder data, 31–33
Default setting, 83
deleting photos, 149–151
depth of field (DoF)
  about, 257–258
  adjusting, 258–261
  checking, 264–265
  defined, 195, 249, 257
  for dynamic close-up photography, 300
  effect of aperture on, 201
  for group portraits, 290
  manipulating, 257–265
  in Portrait mode, 72
  preview, 263
Depth-of-Field Preview button, 264
Digital Print Order Format (DPOF), 186
digital terminal, 25
diopters, 301
dioptric adjustment control, 13
disabling
  AEB (automatic exposure bracketing), 234
  AF-assist beam, 340–341
  auto bracketing, 232–234
  automatic rotation, 138
  Image Review, 131–132
  Peripheral Illumination Correction, 228
  Shooting Settings screen, 29, 345–346
Disp button, 22
Display Calibrator Assistant, 184
Display Color Calibration, 184
displaying
  camera settings, 25–34
  displays on TVs, 100
  grids, 99
  multiple images, 132–134
  photos and movies in Live View, 96
  photos on televisions, 160–161
  picture data, 141–149
  picture settings, 109–114
  pictures in Playback Mode, 132–141

displays. *See also* screens
  Camera Settings, 33–34
  Live View, 98–100
  Shooting Settings, 28–30
  viewing on TVs, 100
DoF (depth of field)
  about, 257–258
  adjusting, 258–261
  checking, 264–265
  defined, 195, 249, 257
  for dynamic close-up photography, 300
  effect of aperture on, 201
  for group portraits, 290
  manipulating, 257–265
  in Portrait mode, 72
  preview, 263
downloading. *See also* online sharing; printing
  defined, 163
  images with Canon tools, 170–176
DPOF (Digital Print Order Format), 186
Drive mode
  about, 72
  changing, 43–47
  in Close-up mode, 75
  in Creative Auto mode, 91
  in Landscape mode, 75
  in Night Portrait mode, 78
  in Portrait mode, 73
  in Sports mode, 77
dynamic close-up photography, 300–302

• E •

eCheat Sheet, 4
editing
  adding text, 332–333
  adjusting color balance, 320–321
  adjusting color saturation, 317–319
  adjusting exposure, 322–328
  Auto Adjustment option, 331–332
  cropping images, 314–317
  movies, 125–127
  opening images, 307–312
  removing red-eye, 312–313
  saving images, 307–312
  sharpening focus, 328–331
EF (electro focus), 8
Electro Optical System (EOS), 40
eliminating color casts with Shoot by Lighting or Scene Type option, 82–84
Embed ICC Profile in Image, 179–180
enabling
  auto bracketing, 232–234
  copyright feature, 349–351
  flash in advanced exposure modes, 50
  Highlight Tone Priority, 222–223
  Live View for still photography, 94
  Shooting Settings display, 29
  White Balance Bracketing, 274–276
EOS (Electro Optical System), 40
EOS Utility, 171–174
E-TTL II, 237
E-TTL II Metering option, 247
Evaluative metering, 208
exiting Live View, 96
exposure. *See also* lighting
  about, 195
  adjusting, 322–328
  advanced modes, 196–197
  aperture, 197–198
  balancing, 204–205
  bracketing, 230–235
  choosing metering modes, 208–210
  correction tools, 216–228
  customizing lock options, 338–339
  in Flash Off mode, 70
  in Full Auto mode, 70
  ISO, 197–200
  locking for flash, 244–245
  monitoring settings, 205–208
  for scenic photography, 298–299
  setting f-stop, 214–216
  setting ISO, 210–212
  shutter speed, 197–199, 214–216
  side effects, 200–204
Exposure Compensation
  automatic exposure bracketing (AEB) in, 231
  Movie Menu 3, 123
  overriding autoexposure with, 216–220
  setting, 207
exposure correction tools
  Exposure Compensation, 216–220
  Highlight Tone Priority, 220–226
  Peripheral Illumination Correction, 226–228
exposure meter, 206

exposure metering mode, 208–210
exposure modes. *See also* Creative Zone category; *specific exposure modes*
  automatic exposure bracketing (AEB) in, 231
  choosing, 42–43
  selecting with Mode dial, 18
exposure modes, advanced. *See also* Creative Zone category; *specific exposure modes*
  about, 196–197
  enabling flash in, 50
  using flash in, 235–247
Exposure Simulation, 113
exposure stops, 222
Exp.SIM symbol, 113
external camera controls
  back-of-the-body, 19–23
  connection ports, 24–25
  front, 23–24
  topside, 17–19
external flash. *See also* flash
  controls, 247
  for still portraits, 291
Eye-Fi memory card
  about, 36, 168, 351–352
  installing software, 352–354
  setup, 351–356
  transfer speeds, 356
  using, 354–356
Eye-Fi Settings option (Setup Menu 1), 36

• F •

face detection
  Live mode with, 103
  using Live mode with, 108–109
Faithful Picture Style, 279–280
FE Lock (Flash Exposure Lock), 244–245
Feature Guide option (Setup Menu 2), 38–39
File Numbering option (Setup Menu 1), 35–36
files
  JPEG, 61–62
  Raw (CR2), 62–64, 176–180
  size, 58–59
  tagging with copyright data, 349–351
  types, 60–64
fill flash, 48, 237, 301
filters
  color balancing, 321
  Level Adjustment, 322–324
  neutral-density, 298
  Tone Curve Adjustment, 325–328
  Unsharp Mask, 329
fine-tuning White Balance settings, 271–273
fireworks, shooting, 303
firmware, 3, 227
Firmware Ver. option (Setup Menu 3), 39
1st curtain sync, 247
flash
  about, 47, 237
  adjusting power with Flash Exposure Compensation, 242–244
  automatic exposure bracketing (AEB) in, 231
  in Close-up mode, 75
  in Creative Auto mode, 91–92
  enabling in advanced exposure modes, 50
  external controls, 247
  fill, 48, 237, 301
  in Flash Off mode, 70
  force, 48
  in Full Auto mode, 70
  for indoor photography, 301
  for indoor portraits, 288–289, 291–293
  in Landscape mode, 75
  locking exposure, 244–245
  in Night Portrait mode, 78
  for nighttime portraits, 291–293
  options, 245–247
  for outdoor photography, 240–242
  for outdoor portraits, 289
  in Portrait mode, 73–74
  Red-Eye Reduction flash mode, 34, 291
  in Sports mode, 77
  using in advanced exposure modes, 235–247
  using in Creative Auto mode, 48–49
  using in fully automatic modes, 48
  using Red-Eye Reduction flash, 50–51
Flash button, 19, 341–342
flash diffuser, 292
Flash Exposure Compensation
  adjusting flash power with, 242–244
  option, 247
Flash Exposure Lock (FE Lock), 244–245

Flash Firing option, 246
Flash hot shoe, 19
flash metering, 237–240
Flash Mode option, 246
Flash Off mode
  about, 42
  flash in, 48, 235
  Picture Styles in, 280
  using, 66–70
flowers, shooting, 301
Fluorescent Light setting, 84
focal length (lens), 259, 262
Focal plane indicator, 19
focus
  about, 100, 249–252
  autofocus, 102–109
  customizing lock options, 338–339
  for dynamic close-up photography, 300
  manual, 101–102
  sharpening, 328–331
  shifting from autofocus to manual focus, 11–13
  viewfinder, 13–14
folders, creating, 348–349
force flash, 48
Format option (Setup Menu 1), 35
formatting memory cards, 17
frame rate, 121
framing subjects, 290
Freespace, 33
f-stop
  about, 197–198, 201
  adjusting, 214–216
  adjusting depth of field with, 258, 260
  effect on depth of field, 201
  in Portrait mode, 73
  setting, 214–216
  setting in Portrait mode, 73
Full Auto mode
  about, 42
  flash in, 235
  Picture Styles in, 280
  using, 66–70
  using flash in, 48
full stop, 217
fully automatic exposure modes, 48. *See also* Basic Zone category
functions, changing of Set button, 335–337

• G •

gamut, 277
glass, shooting through, 302
grayscale images, 279
Grid Display (Movie Menu 2), 122
grids, displaying, 99
group portraits, 290

• H •

halos, sharpening, 329
handling memory cards, 17
HDMI CEC TV sets, 160–161
HDMI terminal, 25
HDR imaging, 230
HDR photography, 230
HDR Photography Photo Workshop (Carr and Correll), 232, 299
HDTV playback, 160
High Dynamic Range Digital Photography For Dummies (Correll), 232, 299
high-capacity SD card (SDHC), 16–17
high-contrast shots, 220–226
Highlight Tone Priority, 121, 220–226
highlights, 147
Histogram display mode, 142, 146–149
histograms
  brightness, 99, 144, 147–148
  RGB, 148–149
hot shoe, 19

• I •

icons, explained, 3
image playback
  deleting photos, 149–151
  Image Review, 131–132
  Playback Mode, 132–141
  presenting slide shows, 156–160

protecting photos, 151–154
rating photos, 154–156
viewing on television, 160–161
viewing picture data, 141–149
image quality
about, 52
controlling, 52–56
options, 54–56
troubleshooting problems with, 52–54
Image Quality icon, 143
Image Review, 131–132
image settings
about, 41, 285–287
adjusting, 109–114
changing Drive mode, 43–47
choosing exposure modes, 42–43
controlling picture quality, 52–56
file type, 60–64
flash, 47–51
resolution, 56–60
viewing, 109–114
Image Zone modes, 42
ImageBrowser (Mac), 164–165
images
adding cleaning instructions to, 342–345
cropping, 314–317
deleting, 149–151
downloading with Canon tools, 170–176
grayscale, 279
jumping through, 135–137
opening, 307–312
preparing for online sharing, 186–192
protecting, 151–154
rating, 142, 154–156
resizing in-camera, 188
RGB, 148
rotating, 137–139
saving, 307–312
sending to computers, 167–176
shooting in Live View, 95–96
viewing data, 141–149
viewing in Live View, 96
viewing in Playback Mode, 132–141
viewing on televisions, 160–161
imaging (HDR), 230
Index display mode, 134
indoor photography, flash for, 301
indoor portraits, 288–289, 291–293
inserting memory cards, 16
installing Eye-Fi software, 352–354
Intense setting, 80
Internet resources
Adobe, 166–167
Apple, 165, 166
Canon, 3, 39, 168, 237
Datacolor, 184
eCheat Sheet, 4
Eye-Fi memory cards, 168
Pantone, 184
Strobist, 237
iPhoto (Apple), 165
IS (Image Stabilizer) lens, 10–11
ISO
about, 197–200
effect on noise, 202–204
range in Highlight Tone Priority, 221
setting, 210–212

• J •

JPEG artifacts, 53
JPEG compression, 56
JPEG files, 61–62
jumping through images, 135–137

• K •

Kelvin scale, 265

• L •

Landscape mode, 42, 48, 74–75
landscape photography
about, 297
tips for, 297–300
Landscape Picture Style, 279–280
Language option (Setup Menu 2), 38
launching
Automatic White Balance (AWB) setting, 266
Drive modes, 45
images, 307–312
White Balance Correction, 271–273

LCD Brightness option (Setup Menu 2), 36–37
LCD monitor, 14–16
LCD Off/On Button option (Setup Menu 2), 37
Lens focal length, 259–260
Lens release button, 24
lenses
  about, 8
  attaching, 8–10
  correcting vignetting, 226–228
  focal length, 259–260, 262
  IS (Image Stabilizer), 10–11
  lens/sensor dirt, 54
  macro, 301
  registering your lens, 227
  removing, 10
  shifting from autofocus to manual focus, 11–13
  telephoto, 236, 262
  wide angle, 262
Level Adjustment filter, 322–324
lighting. *See also* aperture; exposure
  about, 195
  bracketing to improve, 300
  for indoor portraits, 291
Live mode
  about, 103
  autofocusing, 107–108
  with face detection, 103
  using with face detection AF, 108–109
Live View
  about, 93
  customizing display, 98–100
  customizing movie recording settings, 119–124
  drawbacks, 15–16
  editing movies, 125–127
  enabling for still photography, 94
  exiting, 96
  playing movies, 124–125
  recording movies in, 96, 116–118
  safety tips, 96–98
  shooting in, 95–96, 114–116
  shooting still pictures in, 109–116
  switching to, 94–95
  using, 94–96
  viewing photos and movies in, 96
Live View Shooting, 33
Live View/Movie button, 21
locking
  autoexposure settings, 228–230
  flash exposure, 244–245
  memory cards, 17
Long Exposure Noise Reduction, 213
lossy compression, 61

• M •

M (manual exposure)
  about, 197
  changing exposure settings in, 215
  flash in, 240
  Picture Styles in, 281
Mac
  accessing ZoomBrowser EX, 174
  Display Calibrator Assistant, 184
  ImageBrowser, 164–165
macro lens, 301
“magic hours”, 299–300
magnification factor, 262
magnification frame, 101
Main dial, 19
managing
  color, 265–277
  depth of field, 257–265
  ISO, 211–212
  picture quality, 52–56
manual exposure (M)
  about, 197
  changing exposure settings in, 215
  flash in, 240
  Picture Styles in, 281
manual focus
  about, 101–102
  shifting from autofocus to, 11–13
Manual Reset file numbering, 36
maximum burst frames, 32
megapixels, 57
memory buffer, 32

memory cards
about, 16–17
capacity, 60
reader, 168
memory cards, Eye-Fi
about, 36, 168, 351–352
installing software, 352–354
setup, 351–356
transfer speeds, 356
using, 354–356
MemoryCard Utility, 174–176
Menu button, 23
menus
buttons, 23
camera settings, 26–28
creating, 346–348
customizing, 348
Movie Menu, 27
Movie Menu 1, 120–121
Movie Menu 2, 121–122
Movie Menu 3, 123–124
Playback Menu, 26
Playback Menu 2, 136, 155
Setup Menu, 26–27
Setup Menu 1, 34–36
Setup Menu 2, 36–39
Setup Menu 3, 39
Shooting Menu, 26
Shooting Menu 1, 54–56
Shooting Menu 2, 103–104, 210, 219, 243–244, 282
Shooting Menu 4, 103–104
using, 26–28
metadata, 39, 349
metering (flash), 237–240
metering mode, 207. *See also* exposure metering mode
Metering Timer, 100, 122
microphone, 23
Microsoft Windows
accessing ZoomBrowser EX, 174
Canon ZoomBrowser EX, 164–165
Display Color Calibration, 184
Photo Gallery, 165
midtones, 147
Mode dial, 18
modes
On, 48
AI Focus, 255–256
AI Servo, 255
Auto, 48
Basic Information, 142–143
burst, 44
Close-up, 42, 48, 75–76
Continuous, 44, 235
exposure metering, 208–210
fully automatic exposure, 48
Histogram, 142, 146–149
Image Zone, 42
Index display, 134
Landscape, 42, 48, 74–75
Movie, 43
Night Portrait, 42, 48, 77–78
Off, 49
One Shot, 255
point-and-shoot, 42–43
Portrait, 42, 48, 72–74
Quick, 102–107
Red-Eye Reduction flash, 34, 50–51, 236, 291
Self-Timer, 235
Self-Timer: 10 second drive, 44
Self-Timer: Continuous drive, 44–45
Shooting Information, 142, 144–146
Sports, 42, 48, 76–77
modes, advanced exposure
about, 196–197
enabling flash in, 50
using flash in, 235–247
modes, AF (autofocus)
about, 102–109, 252
adjusting performance, 252–257
changing, 255–257
choosing combinations, 257
setting, 256–257
setting AF mode with button, 256
shifting to manual focus from, 11–13
modes, Creative Auto
about, 42, 87–92
flash in, 235
Picture Styles in, 280
relationship with depth of field, 261
using flash in, 48–49

modes, Drive
about, 72
changing, 43–47
in Close-up mode, 75
in Creative Auto mode, 91
in Landscape mode, 75
in Night Portrait mode, 78
in Portrait mode, 73
in Sports mode, 77
modes, exposure
about, 196–197
automatic exposure bracketing (AEB) in, 231
choosing, 42–43
enabling flash in, 50
selecting with Mode dial, 18
using flash in, 235–247
modes, Flash Off
about, 42
flash in, 235
Picture Styles in, 280
using, 66–70
using flash in, 48
modes, Full Auto
about, 42
flash in, 235
Picture Styles in, 280
using, 66–70
using flash in, 48
modes, Live
about, 103
autofocusing, 107–108
with face detection, 103
using with face detection AF, 108–109
modes, metering, 207. *See also* exposure metering mode
modes, Scene
about, 71
Close-up mode, 75–76
flash in, 235
Landscape mode, 74–75
modifying results, 78–87
Night Portrait mode, 77–78
Picture Styles in, 280
Portrait mode, 72–74
relationship with depth of field, 262
Sports mode, 76–77
using, 71–72
modes, Single
about, 44
AEB in, 235
modifying
AF (autofocus) mode, 255–257
aperture, 214–216
autofocus performance, 252–257
automatic rotation, 138
camera settings, 25–34
color balance, 320–321
color saturation, 317–319
depth of field, 258–261
Drive mode, 43–47
exposure, 322–328
flash power with Flash Exposure Compensation, 242–244
functions of Set button, 335–337
Image Review, 131–132
picture settings, 109–114
Picture Styles, 282
Scene mode results, 78–87
settings with Quick Control button, 112
"Shoot by" settings, 84–87
Shooting Settings display settings, 29
shutter speed, 214–216
White Balance setting, 267–268
monitoring exposure settings, 205–208
monitors
LCD, 14–16
profile, 184
syncing color with print color, 183–186
Monochrome Picture Style, 279–280
Monochrome setting, 80
motion blur, effect of shutter speed on, 202
MOV format, 116
Movie Menu, 27
Movie Menu 1, 120–121
Movie Menu 2, 121–122
Movie Menu 3, 123–124
Movie mode, 43
Movie Recording Size (Movie Menu 2), 121–122

movies
  customizing recording settings, 119–124
  editing, 125–127
  playing, 124–125
  recording in Live View, 96, 116–118
  viewing in Live View, 96
My Menu, 27

• N •

nature scenes, 301
navigating editing window, 309–311
Neutral Picture Style, 279–280
neutral-density filter, 298
Night Portrait mode, 42, 48, 77–78
nighttime photography, 299
nighttime portraits, 291–293
noise
  about, 53, 70, 97
  dampening, 213
  effect of ISO on, 202–204
  in Peripheral Illumination Correction, 228
NR/Lens/ALO tab, 178

• O •

Off mode, 49
On mode, 48
One Shot mode, 255
online resources
  Adobe, 166–167
  Apple, 165–166
  Canon, 3, 39, 168, 237
  Datacolor, 184
  eCheat Sheet, 4
  Eye-Fi memory cards, 168
  Pantone, 184
  Strobist, 237
online sharing, preparing pictures for, 186–192
On/Off switch, 18
opening
  Automatic White Balance (AWB) setting, 266
  Drive modes, 45
  images, 307–312
  White Balance Correction, 271–273
orientation, 137
outdoor photography
  fill flash for, 301
  flash for, 240–242
outdoor portraits, 289
Output Resolution option, 179
overriding autoexposure results with Exposure Compensation, 216–220

• P •

P (programmed autoexposure)
  about, 196
  changing exposure settings in, 214
  exposure compensation in, 220
  flash in, 239
  Picture Styles in, 281
  settings, 208
Pantone huey PRO, 184
Partial metering, 208
Peripheral Illumination Correction, 226–228
photo editing programs, 166–167
Photo Gallery (Windows), 165
photograph playback
  deleting photos, 149–151
  Image Review, 131–132
  Playback Mode, 132–141
  presenting slide shows, 156–160
  protecting photos, 151–154
  rating photos, 154–156
  viewing on television, 160–161
  viewing picture data, 141–149
photograph quality
  about, 52
  controlling, 52–56
  options, 54–56
  troubleshooting problems with, 52–54
photograph settings
  about, 41, 285–287
  adjusting, 109–114
  changing Drive mode, 43–47
  choosing exposure modes, 42–43
  controlling picture quality, 52–56
  file type, 60–64
  flash, 47–51
  resolution, 56–60
  viewing, 109–114

photographs
  adding cleaning instructions to, 342–345
  cropping, 314–317
  deleting, 149–151
  downloading with Canon tools, 170–176
  grayscale, 279
  jumping through, 135–137
  opening, 307–312
  preparing for online sharing, 186–192
  protecting, 151–154
  rating, 142, 154–156
  resizing in-camera, 188
  RGB, 148
  rotating, 137–139
  saving, 307–312
  sending to computers, 167–176
  shooting in Live View, 95–96
  viewing data, 141–149
  viewing in Live View, 96
  viewing in Playback Mode, 132–141
  viewing on televisions, 160–161
photography. *See also specific topics*
  bracketed series, 235
  from car windows, 303
  dynamic close-up, 300–302
  fireworks, 303
  flowers, 301
  HDR, 230
  in Live View, 114–116
  photos in Live View, 95–96
  still pictures in Live View, 109–116
  still portraits, 287–293
  in strong backlighting, 303–304
  through glass, 302
photography, action
  about, 293
  autofocus combinations for, 257
  techniques for, 294–297
photography, landscape
  about, 297
  tips for, 297–300
photography, outdoor
  fill flash for, 301
  flash for, 240–242
photography, scenic
  about, 297
  tips for, 297–300
photography, still
  autofocus combinations for, 257
  enabling Live View for, 94
  locking autoexposure settings, 229
  selecting Picture Styles for, 281–282
  shooting in Live View, 109–116
  shooting still portraits, 287–293
Photoshop (Adobe), 167
Photoshop Elements (Adobe), 166
Photoshop Lightroom (Adobe), 166
PictBridge, 186
picture playback
  deleting photos, 149–151
  Image Review, 131–132
  Playback Mode, 132–141
  presenting slide shows, 156–160
  protecting photos, 151–154
  rating photos, 154–156
  viewing on television, 160–161
  viewing picture data, 141–149
picture quality
  about, 52
  controlling, 52–56
  options, 54–56
  troubleshooting problems with, 52–54
picture settings
  about, 41, 285–287
  adjusting, 109–114
  changing Drive mode, 43–47
  choosing exposure modes, 42–43
  controlling picture quality, 52–56
  file type, 60–64
  flash, 47–51
  resolution, 56–60
  viewing, 109–114
Picture Style (Movie Menu 3), 124
Picture Style Editor, 283
Picture Styles
  about, 279
  advanced, 282–284
  basic, 279–280
  relationship with exposure mode, 280–281
  for still photography, 281–282
pictures
  adding cleaning instructions to, 342–345
  cropping, 314–317
  deleting, 149–151

downloading with Canon tools, 170–176
grayscale, 279
jumping through, 135–137
opening, 307–312
preparing for online sharing, 186–192
protecting, 151–154
rating, 142, 154–156
resizing in-camera, 188
RGB, 148
rotating, 137–139
saving, 307–312
sending to computers, 167–176
shooting in Live View, 95–96
viewing data, 141–149
viewing in Live View, 96
viewing in Playback Mode, 132–141
viewing on televisions, 160–161
pixel count, checking, 180–182
pixel dimensions, 57
pixelation, 52–53
planning your printing, 180–186
playback, picture
deleting photos, 149–151
Image Review, 131–132
Playback Mode, 132–141
presenting slide shows, 156–160
protecting photos, 151–154
rating photos, 154–156
viewing on television, 160–161
viewing picture data, 141–149
Playback button, 23
Playback Menu, 26
Playback Menu 2
jumping through images with, 136
rating photos in, 155
Playback Mode, viewing pictures in, 132–141
playing movies, 124–125
point-and-shoot modes, 42–43
Portrait mode, 42, 48, 72–74
Portrait Picture Style, 279–280
portraits, still
shooting, 287–293
tips for, 290–293
ports (connection), 24–25
posterization, 63
preparing pictures for online sharing, 186–192
presenting slide shows, 156–160
preserving battery life, 29
previewing
depth of field, 263
“Shoot by” settings, 84–87
printing. *See also* downloading; online sharing
computerless, 186
pixel count, 180–182
planning, 180–186
print size, 58
printer profiles, 185
proportions, 182–183
syncing print and monitor colors, 183–186
processing Raw (CR2) files, 176–180
profiles
monitor, 184
printer, 185
programmed autoexposure (P)
about, 196
changing exposure settings in, 214
exposure compensation in, 220
flash in, 239
Picture Styles in, 281
settings, 208
proportions (printing), 182–183
Protected status icon, 142
protecting
LCD monitor, 14–15
photos, 151–154

• Q •

quality (picture)
about, 52
controlling, 52–56
options, 54–56
troubleshooting problems with, 52–54
Quick Control button, 112
Quick Control screen
about, 30–31, 103
accessing exposure compensation with, 219
adjusting flash power with, 243
adjusting ISO with, 212
changing metering mode with, 209–210
changing White Balance setting with, 268

Quick Control screen *(continued)*
jumping through images with, 136
overriding autoexposure with, 218
quality options, 54
raising flash via, 236
rating photos in, 155
selecting Picture Styles with, 281–282
setting AF mode with, 256–257
using during playback, 134–135
Quick Control/Direct Print button, 22
Quick mode, 102–107

• R •

rating photos, 142, 154–156
Raw (CR2) files, 62–64, 176–180
RAW+ Large/Fine setting, 64
RAW setting, 64
Raw tab, 177–178
reading RGB histograms, 148–149
rear-curtain sync, 247
reassigning Flash button, 341–342
recording movies in Live View, 96, 116–118
red-eye, removing, 312–313
Red-Eye Reduction flash mode, 34, 50–51, 236, 291
Red-Eye Reduction/Self-Timer Lamp, 24
reducing shadowing from flash, 292
registering your lens, 227
Release Shutter without Card, 40
Remember icon, 3
remote control terminal, 25
removing
lenses, 10
memory cards, 17
photos, 149–151
red-eye, 312–313
resizing photos in-camera, 188
resolution
about, 56–57, 180–182
file size, 58–59
memory card capacity, 60
print size, 58
recommendations, 59
relationship with quality, 57
screen display size, 58
resources (Internet)
Adobe, 166–167
Apple, 165–166
Canon, 3, 39, 168, 237
Datacolor, 184
eCheat Sheet, 4
Eye-Fi memory cards, 168
Pantone, 184
Strobist, 237
reviewing setup options, 34–40
RGB histograms, 148–149
RGB images, 148
RGB tab, 178
rotating pictures, 137–139
running slide shows, 156–160

• S •

S (short back focus), 8
saturation (color), 317–319
saving images, 307–312
Scene modes
about, 71
Close-up mode, 75–76
flash in, 235
Landscape mode, 74–75
modifying results, 78–87
Night Portrait mode, 77–78
Picture Styles in, 280
Portrait mode, 72–74
relationship with depth of field, 262
Sports mode, 76–77
using, 71–72
scenic photography
about, 297
tips for, 297–300
Screen Color option (Setup Menu 1), 36
screens. *See also* displays
display size, 58
Shooting Settings, 345–346
screens, Quick Control
about, 30–31, 103
accessing exposure compensation with, 219
adjusting flash power with, 243
adjusting ISO with, 212

changing metering mode with, 209–210
changing White Balance setting with, 268
jumping through images with, 136
overriding autoexposure with, 218
quality options, 54
raising flash via, 236
rating photos in, 155
selecting Picture Styles with, 281–282
setting AF mode with, 256–257
using during playback, 134–135
SD (Secure Digital) card, 16–17
SDHC (high-capacity SD card), 16–17
2nd curtain sync, 247
Secure Digital (SD) card, 16–17
Select Folder option (Setup Menu 1), 36
selecting
autofocus combinations, 257
color space, 277–279
exposure metering mode, 208–210
exposure modes, 42–43
functions on menus, 28
menus, 28
photo software, 163–167
resolution, 181
Self-Timer: 10 second drive mode, 44
Self-Timer: Continuous drive mode, 44–45
Self-Timer modes, 235
sending pictures to computers, 167–176
sensor dirt, 54
Set button, 22, 335–337
settings
adjusting with Quick Control button, 112
AF mode, 256–257
autoexposure, locking, 228–230
download preferences in EOS Utility, 173
exposure, monitoring, 205–208
Exposure Compensation, 207
f-stop, 214–216
ISO, 210–212
movie recording, 119–124
picture, 285–287
“Shoot by,” 84–87
shutter speed, 214–216
settings, camera
about, 25
adjusting, 25–34
Camera Settings display, 33–34
menus, 26–28
Quick Control screen, 30–31
Shooting Settings display, 28–30
viewfinder data, 31–33
viewing, 25–34
settings, picture
about, 41, 285–287
adjusting, 109–114
changing Drive mode, 43–47
choosing exposure modes, 42–43
controlling picture quality, 52–56
file type, 60–64
flash, 47–51
resolution, 56–60
viewing, 109–114
setup
Eye-Fi memory card, 351–356
reviewing options, 34–40
Setup Menu, 26–27
Setup Menu 1, 34–36
Setup Menu 2, 36–39
Setup Menu 3, 39
Shade setting, 83
sharing. *See* downloading; online sharing; printing
sharpening
about, 279
focus, 328–331
halos, 329
shifting from autofocus to manual focus, 11–13
Shoot by Ambience option, 72, 79–82, 89
Shoot by Lighting or Scene Type option, 72, 79, 82–84
“Shoot by” settings, 84–87
shooting. *See also specific topics*
bracketed series, 235
from car windows, 303
fireworks, 303
flowers, 301
in Live View, 114–116
photos in Live View, 95–96
still pictures in Live View, 109–116
still portraits, 287–293
in strong backlighting, 303–304
through glass, 302
Shooting Information mode, 142, 144–146

Shooting Menu, 26
Shooting Menu 1, 54–56
Shooting Menu 2
  about, 103–104
  accessing exposure compensation with, 219
  adjusting flash power with, 243–244
  changing metering mode with, 210
  selecting Picture Styles with, 282
Shooting Menu 4, 103–104
Shooting Settings screen
  about, 28–30
  disabling, 345–346
short back focus (S), 8
shutter button
  about, 19, 37
  for still portraits, 290
shutter speed
  about, 197–199
  adjusting, 214–216
  effect on motion blur, 202
  for indoor portraits, 291
  for nighttime photography, 299
  relationship with blurry photos, 251
  relationship with depth of field, 263
  relationship with flash, 236
  for scenic photography, 298
  setting, 214–216
Shutter Sync option, 246–247
Shutter/AE Lock button (Movie Menu 1), 121
shutter-priority autoexposure (Tv), 196
  about, 196
  changing exposure settings in, 214
  exposure compensation in, 220
  flash in, 239
  Picture Styles in, 281
  settings, 207
Single mode
  about, 44
  AEB in, 235
size
  file, 58–59
  print, 58
  screen display, 58
slide shows, presenting, 156–160
Soft setting, 80
softening backgrounds, 288
software
  Adobe Photoshop, 167
  Adobe Photoshop Elements, 166
  Adobe Photoshop Lightroom, 166
  book, 4
  choosing, 163–167
  tone mapping, 230
Sound Recording (Movie Menu 2), 122
speaker, 21
special situations, 302–304
speed (shutter)
  about, 197–199
  adjusting, 214–216
  effect on motion blur, 202
  for indoor portraits, 291
  for nighttime photography, 299
  relationship with blurry photos, 251
  relationship with depth of field, 263
  relationship with flash, 236
  for scenic photography, 298
  setting, 214–216
Sports mode, 42, 48, 76–77
sRGB color space, compared with Adobe RGB, 277–279
Standard Picture Style, 279–280
Standard setting, 80
still photography
  autofocus combinations for, 257
  enabling Live View for, 94
  locking autoexposure settings, 229
  selecting Picture Styles for, 281–282
  shooting in Live View, 109–116
  shooting still portraits, 287–293
still portraits
  shooting, 287–293
  tips for, 290–293
storing Picture Styles, 283
Strobist (website), 237
styles (Picture)
  about, 279
  advanced, 282–284
  basic, 279–280
  relationship with exposure mode, 280–281
  for still photography, 281–282
subjects, framing, 290
sunrise shots, 299

Sunset setting, 84
sunset shots, 299
switching to Live View, 94–95
syncing print and monitor colors, 183–186

• T •

tagging files with copyright data, 349–351
Technical Stuff icon, 3
telephoto lenses
  focal length, 262
  relationship with flash, 236
televisions
  viewing displays on, 100
  viewing photos on, 160–161
temperature (color), 265
text, adding, 332–333
Time, 34
Tip icon, 3
tonal range, 147
Tone Curve Adjustment filter, 325–328
tone mapping software, 230
tools
  Canon, downloading with, 170–176
  color management, 185
  Exposure Compensation, 216–220
  exposure correction, 216–228
  Highlight Tone Priority, 220–226
  Peripheral Illumination Correction, 226–228
transfer process, 170
transfer speeds, 356
Tungsten Light setting, 83
turning off
  AEB (automatic exposure bracketing), 234
  AF-assist beam, 340–341
  auto bracketing, 232–234
  automatic rotation, 138
  Image Review, 131–132
  Peripheral Illumination Correction, 228
  Shooting Settings screen, 29, 345–346
turning on
  auto bracketing, 232–234
  copyright feature, 349–351
  flash in advanced exposure modes, 50
  Highlight Tone Priority, 222–223
  Live View for still photography, 94
  Shooting Settings display, 29
  White Balance Bracketing, 274–276
Tv (shutter-priority autoexposure)
  about, 196
  changing exposure settings in, 214
  exposure compensation in, 220
  flash in, 239
  Picture Styles in, 281
  settings, 207
TVs
  viewing displays on, 100
  viewing photos on, 160–161

• U •

Unsharp Mask filter, 329
USB cable, 168
USB connection terminal, 25

• V •

verifying
  background, 290
  Camera Settings display, 33–34
  depth of field, 264–265
vibration compensation, 10–11
video
  customizing recording settings, 119–124
  editing, 125–127
  playing, 124–125
  recording in Live View, 96, 116–118
  viewing in Live View, 96
viewfinder
  decoding data, 31–33
  focus, 13–14
viewing
  camera settings, 25–34
  displays on TVs, 100
  grids, 99
  multiple images, 132–134
  photos and movies in Live View, 96
  photos on televisions, 160–161
  picture data, 141–149
  picture settings, 109–114
  pictures in Playback Mode, 132–141
vignetting, 226–228
Vivid setting, 80

• W •

Warm setting, 80
Warning! icon, 3
WB button, 267–268
websites
  Adobe, 166–167
  Apple, 165–166
  Canon, 3, 39, 168, 237
  Datacolor, 184
  eCheat Sheet, 4
  Eye-Fi memory cards, 168
  Pantone, 184
  Strobist, 237
white balance
  changing setting, 267–268
  correcting color with, 265–267
  creating custom settings, 269–271
  defined, 82, 249
  fine-tuning settings, 271–273
  tips, 290
White Balance Bracketing, 274–277
White Balance Correction, 271–273
White Balance Shift/Bracketing, 33
wide angle lens, 262
Windows
  accessing ZoomBrowser EX, 174
  Canon ZoomBrowser EX, 164–165
  Display Color Calibration, 184
  Photo Gallery, 165

• Z •

ZoomBrowser EX/ImageBrowser, 166, 307–312
zooming, 13, 140–141, 300

Notes

Notes

Notes

Notes